



Restoration Ready-to-Install Auto Upholstery & Carpet Kits
DashCare Brand Dash Covers for all Vehicles

1575 W. Broadway Ave., Anaheim, CA 92802

Tel: 800 - 235 - 8974 or 714 - 774 - 9506 Fax: 714 - 774 - 0788 sales@seatzmfg.com



VELCRO VERSION - TONNEAU COVER INSTALL INSTRUCTIONS

1. Test fit the Tonneau to get an idea of the fastening points of the Sewn-on Loop Velcro. This is best done with a second person as a helper. Stretch hard across and note where to position the hook.
2. Thoroughly clean all surfaces of the pickup bed where you will be applying the Adhesive Backed Hook Velcro. The Metal surface must be free of wax, residues and oxidation. Wait at least a month to install on new paint.
3. Apply Velcro Hook **FIRMLY** to the metal, especially at the ends. The best technique is to peel back a small portion of the protective tape, position and apply the exposed adhesive Velcro at one end, pull the Velcro tight from the other side to form a straight line and then gently peel back the protective tape and press the adhesive backed Hook down on the metal.
4. Go back over the Velcro Hook with pressure from your fingers to assure a good bond of all surfaces. **DO NOT** Reposition the adhesive backed Hook! Avoid touching the adhesive.
5. **DO NOT INSTALL THE TONNEAU COVER FOR 48-72 HOURS!** The adhesive is activated by pressure and has less than a third of its final strength immediately after installation! If it is repositioned, it will never attain its full strength potential.

SNAP-ON VERSION - TONNEAU COVER INSTALL INSTRUCTIONS

1. Position the supplied ABS Rails on top of the front wall of the pickup bed with the open channel facing forward toward the cab. The Rails come in two pieces for easier shipping. Position the rails with the ends touching each other at the center (no space). Trim their length if needed.
2. Drill holes through the rails and into the bed wall top. Size the hole properly for the screws and truck bed wall thickness. Use stainless screws and install the rails.
3. Feed the edge with the sewn-in round cord into the Rail Channel and center the Tonneau Cover across the front wall. The corded edge may slip out when pulled directly away from the channel but will not pull out when pulled back toward the rear. Use spray silicone as needed.
4. Next, install the Snap Screw Studs. Start with the front outer corners - the forward most snaps on the sides closest to the front wall. Pull the Tonneau Cover tight across the bed before marking a spot to drill – **THIS IS BEST DONE WITH TWO PEOPLE**. Mark, drill and install **ONE** Snap Screw Stud on each side and attach the Tonneau Cover.
5. Next, install the Snap Screw Studs at the **BACK** outer rear corners of the side bed rails. Make sure you pull the Tonneau Cover **Tight** for the best look.
6. Next install the Snap Screw Stud for the Rear Gate center.
7. Next, install the remaining Studs on the Rear Gate working outward from the center.
8. Last, install the Studs on the side bed rails starting in the middle. Alternate sides and work outboard from the middle.

